


# Omnetics NeuroNexus A16 Adapter

PN-8689



## Blackrock Microsystems, LLC

630 Komas Drive • Suite 200  
Salt Lake City • UT 84108

T: +1 (801) 582-5533  
[www.blackrockmicro.com](http://www.blackrockmicro.com)  
[support@blackrockmicro.com](mailto:support@blackrockmicro.com)

# 1 Introduction

This assembly acts as an adapter between NeuroNexus A16 probes and Blackrock's Omnetics 16-ch Headstages used for neural signal transmission. The Omnetics NeuroNexus A16 adapter has a 3" rod that is removable for use with any stereo tax arm that can support a 1/8" (3.175mm) diameter rod. The A16 Adapter also has two solder points for external reference or ground points with a switch to adjust referencing with the headstage.

# 2 Warning




The Omnetics NeuroNexus A16 Adapter is intended for animal research purposes ONLY.

	IEC60101-0102	Danger of Electrostatic Discharge (ESD)
--	---------------	---

- In order to reduce the likelihood of ESD, use antistatic or electrostatic discharge (ESD) safe gloves when connecting the Adapter.
- Do not touch any exposed electrical conductors when the Adapter connector is attached to devices on the subject's head as this may result in inducing electric charge to the neural tissue. Irreversible damage may occur.

# 3 Hardware

## 3.1 Blackrock Omnetics NeuroNexus A16 Adapter PN-8689



## 4 Warranty

Blackrock Microsystems, LLC warrants that its products are free from defects in materials and manufacturing for a period of one year from the date of shipment. Blackrock will, at its option, repair or replace any product that does not comply with this warranty. This warranty is voided by:

1. Any modification or attempted modification to the product done by anyone other than an authorized Blackrock employee
2. Any abuse, negligent handling or misapplication of the product.

This constitutes the sole warranty made by Blackrock. There are no other warranties, expressed or implied, which extend beyond those described herein or to anyone other than the original purchaser, including the implied warranties of merchantability and fitness for a particular purpose. In no event shall Blackrock Microsystems, LLC be liable for any incidental or consequential damages, or for the infringement of any patent rights or third party rights due to the use of its products.

### 4.1 Return Merchandise Authorization (RMA)

In the unlikely event that your adapter needs to be returned to Blackrock for repair or maintenance, do not send any equipment back without a Return Merchandise Authorization Number. An RMA number will be issued to you by a Blackrock representative. If you need to obtain an RMA number, you may contact a product support representative at (801) 582-5533 or toll free at (866) 806-3692.

Once an RMA number has been issued, it is important to safely pack the returned item for shipping back to Blackrock. It is preferred that you save the original boxes and packing materials that your system arrived in for return shipment. Please address the package as follows:

**Blackrock Microsystems, LLC**  
**ATTN: RMA#**  
**630 Komas Drive, Suite 200**  
**Salt Lake City, UT 84108 USA**  
**Tel: +1 (801) 582-5533**